

SCREW RETAINED & OVERDENTURE RESTORATIONS | VARI-CONNECT PROTOCOL

ASSEMBLY OF ANGLED VARI-CONNECT

1

Use the Angle Guide Pin to choose the right correction angle.




2

Attach the Vari-Connect to the appropriate angle. Use the handle as an indicator for the final screw emergence.



3

Tighten the base to 30 Ncm, with the Hex Driver or a Star Driver.



4

Remove the handle by unscrewing it out.




HEALING CAPS ASSEMBLY



IMPRESSION

Choose the desired impression technique:

For closed tray choose Snap-On-Transfer.



For open tray technique choose conventional Transfer.



ASSEMBLY VARI-CONNECT PLATFORM ADAPTER (OR MULTI-UNIT PLATFORM ADAPTER)

1

Select the MU Adapter desired height and connect to the Angle Vari-Connect by using the Driver.



2

Tighten the Adapter at 25-30 Ncm, with a 2.0mm Straight Multi-Unit Driver.



3

Remove the Driver.



SCREW RETAINED & OVERDENTURE RESTORATIONS | VARI-CONNECT PROTOCOL

IMMEDIATE LOADING (FABRICATION OF THE TEMPORARY BRIDGE)

1

Assemble the Titanium Sleeve on the Multi-Unit base and tighten the screw to 25 Ncm.



2

Attach the pre-prepared provisional acrylic prosthesis

LABORATORY PHASE

1

Mount the Plastic Sleeve on the Multi-Unit analog and tighten with the screw.



2

Splint the sleeves.

3

Carve the Sleeves to the desired shape.

4

Invest and cast the metal frame of the prosthesis.

PASSIVE FIT CASTABLE ABUTMENT SET

The Passive Fit Castable Abutment Set consists of three parts aimed for the fabrication of accurate metal reinforced prostheses. The uniquely designed Castable Sleeve Positioner is used for aligning the Castable Sleeve on the plaster model, ensuring passive fit of the fabricated metal cast when cemented to the Titanium Abutments.

Tighten final prosthetic crown/bridge screw to the Vari-Connect Multi-Unit platform at 25Ncm.

